

# **KANE-CO2** Indoor Air Quality Carbon Dioxide Monitor



#### Application

• Used to monitor CO2 concentration, humidity (RH), & temperature (Temp) for indoor air quality monitoring

#### Measures

- Ambient CO2 0-5000ppm
- Temperature 0°C to 90°C (32°F to 195°F)
- Relative humidity (RH) 5-95%

#### Features


- Large display
- Touch button operation
- 15° Bevel design, easy to read
- Low drift NDIR sensor, long lifespan
- Audible & visible alarm
- Chart with variable time zoom levels
- CO2/RH/Temperature monitor tracer
- Auto-calibration & manual calibration
- Max/min value display in real time

#### Contents


• CO2 Monitor unit, USB cable, manual

The Health & Safety Executive (HSE) suggest the use of CO2 monitors to identify poorly ventilated areas to help reduce the risk of COVID aerosol transmission

### **LED** Indicator







| Item | Name                        | ltem | Name   |
|------|-----------------------------|------|--|
| 1    | CO2/RH/TEMP Chart           | 7    | Plant Mode   |
| 2    | Max Reading of Chart        | 8    | Human Mode   |
| 3    | Min Reading of Chart        | 9    | Audible Alarm On/Off                                   |
| 4    | RH Reading                  | 10   | CO2 Reading  |
| 5    | Temperature Reading °C / °F | (1)  | Time per Division - indicates the chart's span of time |
| 6    | Main Menu                   |      |  |

**Customer Service** 



Manchester, M46 0SY, UK

Email: nservice@kane.co.uk

Gibfield Park Avenue, Atherton,

**0800 059 0800** Email: sales@kane.co.uk ner Service Southern & International Customer Service

#### Kane International Ltd

Kane House, 11 Bessemer Road, Welwyn Garden City, Hertfordshire, AL7 1GF, UK Email: sservice@kane.co.uk

Distributed by:

## www.kane.co.uk

Outside UK Call +44 1707 375550

